


INTERIOR MORTISE PASSAGE LATCH

N° 74976 with 2 ½" Backset



Drawing shown at ½ scale. Please do not scale drawing. Template is for reference only, not mortising purposes. All field cutting and fitting should be done with physical hardware.
Please note when mounting hardware, face plate and strike use #12-24 flat head screws.
Universal strikes are supplied with most lockets. Handed strikes available upon request at no additional charge.